activyl

MERCK ACTIVYL POWERWING

IN-STORE ASSEMBLY

Important! There is a bag within the shipping carton containing (5) small Hook Pads (1) large Hook Pad and the Curved Header Card. Please set aside until required.





MERCK ACTIVYL POWERWING

IN-STORE ASSEMBLY

Directions for Proxy Cards Use



Step 1Remove the hook insert that was also used as a shipping insert and set aside.



Step 2Remove the brochure pack
& brochure pocket and hooks.



Step 3Install hooks into each hook insert as shown.



Step 4 Pre-fold flaps of the hook insert as shown.



Install all (6) hook pads into the (6) upper cells as shown. The inserts lean slightly forward when installed.



Step 6Shows hook insert installed ready for proxy cards.



Remove twin-stick protector backing from the back of the pocket.



There are (2) "L" shape cuts to position the bottom corners of the pocket to the vertical graphic panel. Important! Carefully align the pocket then press firmly to get good adhesion to the graphic panel.



MERCK ACTIVYL POWERWING

IN-STORE ASSEMBLY

Directions for Proxy Cards Use



Step 9 Pocket in correct position.



Step 10 Place brochures into pocket before or after hanging the powerwing on the powerwing rack.



Step 11 Install (2) product hooks in the lower hook insert.



Install lower hook insert into lower cell as shown.



Step 13 Place (10) of each optional cards onto hooks as shown.



Step 14
Install the header into upper slots. Slide tabs of header between the 2 layers of corrugate which will keep the header in an upright position.



Step 15 Header intalled correctly.



Step 16
Attach power bar to end cap if needed and hang powerwing by plastic clips. Refer to front cover for products or proxy cards placement order.



MERCK ACTIVYL POWERWING

IN-STORE ASSEMBLY

Directions for Display with Products



Step 1Remove the hook insert that was also used as a shipping insert.



Step 2
Remove the brochure pack
& brochure pocket and hooks.



Remove twin-stick protector backing from the back of the pocket.



Step 4
There are (2) "L" shape cuts to position the bottom corners of the pocket to the vertical graphic panel. Important!
Carefully align the pocket then press firmly to get good adhesion to the graphic panel.



Step 5 Pocket in correct position.



Step 6Place brochures into pocket before or after hanging the powerwing on the powerwing rack.



Step 7
Attach power bar to end cap if needed and hang powerwing by plastic clips. Refer to front cover for products or proxy cards placement order.

